

Double Bar Kit Installation Instructions

1. Install small Black insulator onto the center double bar bracket.
2. Install the center double bar bracket onto the bottom of the center insulator arm. Use the Large vertical hole on the front (Crop side) of the insulator arm.
3. Install the large insulators with the Black Shear Rings pointed to the tractor.
4. Install the outer 2 remaining double bar brackets and their Large insulators.
5. Install the 2 braided straps as shown in photo
6. Route the Red HV cable through the Mounting bracket on the top of the 4" X 4" square tube. It is located beside the center pocket.
7. Route the HV cable across the top of the center insulator arm as shown in Photo
8. Install the copper electrodes. See Manual
9. Connect the HV cable and the Braided cable to the Middle Copper electrode as shown. Use the copper plated clamps that were provided.
10. Connect the opposite end of the braided cable to the small black insulator.
11. Connect the opposite end of the front braided cable to the front copper electrode.

