

Weed Zapper Start Up Instructions

1. Always startup on “Low Weed” selection.
2. Select the HP selection that is just below your tractors rated HP.
3. Install all insulator arms, wires, according to instructional YouTube video
4. Only hook up center HV cable to center section of front electrodes **At this time, leave both ends of all “small gray wing transfer wires” disconnected.**
5. Start the **center section only** 1st. Do this by satisfying all safety’s on the right side of the monitor run screen. This is including generator rpm over 1650 (1000 + PTO RPM’S). The **RED** “Disabled” light that is below the vertical column of safety boxes should turn to **GREEN** “Ready” once safety’s and rpm’s are satisfied.
6. Once you see “Zapper is Running!” displayed on the lower right corner of the monitor you may shock a weed, if there are any present.
7. If no warnings or fault codes display on monitor during this startup, then connect both ends of the **Main** wing transfer wire’s and repeat the entire process.
8. If no warnings or fault codes display on monitor during this startup, then connect both ends of the **Outer** wing transfer wire’s and repeat the entire process.

This is a 2 step process on the 20’ and 30’ with single left and right wings and is a 3 step process on the 40’ booms.