



No Speed No RPM Instructions

Testing steps

1. Turn on monitor and go to run screen
2. Do wing switch test
3. Drive about 50' at 3mph with wings on the ground
4. See if SPEED light turns green (if yes go to point 6.) (if no go to point 5.)
5. Watch speed sensor adjustment video and inspect speed sensor wires and speed sensor
<https://youtu.be/hVgxKHOsZ78?si=P4pJxV1A68xDFCWn>
6. Read No Generator Rpm instructions that is sent and perform test.
<https://theweetzapper.oldschoolmanufacturing.com/support/part-replacement-instructions/no-generator-rpms-flex-boom/>
7. If no rpms are found watch rpm video and perform test on breakers reading OHMS ONLY NO PTO please!
<https://youtu.be/oWZugtTmkvA?si=yDGccBXaZH1Bq49a>